



# 1997-2004 DODGE DAKOTA/ DODGE DURANGO INSTALLATION INSTRUCTION

## List of Hardware

- 4- Single Bolt Plates
- 4- Spring Keepers
- 4- Flat Washer
- 4- Lockers Washers
- 4- Nuts

1. Remove Stock Bumper
2. Unbolt OEM Bumper bracket from frame horn. See View Set aside hardware you will re-use to mount the new bumper bracket
3. Install the single bolt in Inner Bumper push bolt through secure in place with spring keeper. See View B, C
4. Apply Bracket to inner Bumper mount As pictured securing with Flat Washers, Lock Washers, and Nuts View D You will slightly tighten so the bracket still move around for adjustment
5. Now you are ready to install to frame horn. Bracket will slid into the OEM Frame horn. See View E. Use your Stock hardware to tighten to frame horn. Bumper bracket will have in and out up and down side to side adjustment. When you have the bumper in Full adjustment Tighten down bolts

